


SUPVAN



LP 6245A

User Manual

Declaration.....	1
Warning.....	2
Precautions.....	3
Contents.....	4
Specification.....	5
Power Supply.....	6
Insert a Tape Cassette.....	7
LCD Display.....	8
Keyboard.....	9
Functional Keys.....	11
Combination Keys.....	12
Create General Labels.....	13
Create Flag Labels.....	14
Create Wrap Labels.....	15
Create Template Labels.....	16
Label Library.....	17
Connect to computer.....	18
Troubleshooting.....	19
Symbol.....	25
Template Details.....	36
Library Details.....	37

- For any information about the instruction contents, Supvan reserves the right to vary because of the upgrade of the printer.
- Supvan will not be responsible for any consequence caused by operations which do not follow the requirements of manual.
- If you want to know more about the printer or Supvan, please visit: www.supvan.com









Warning

- ⚠ Do not touch the AC adapter and printer during a thunder storm.
- ⚠ Do not damage, or place heavy objects on the power cord or plug. Always hold the AC adapter when disconnecting from the power outlet.
- ⚠ Do not use sharp objects to change the batteries.
- ⚠ Do not touch metal parts around the print head immediately after printing.
- ⚠ Do not touch the cutter blade.
- ⚠ Do not let any metal or liquid get into the printer. This may damage the internal parts of printer or even cause fire or electric shock.
- ⚠ Do not use a battery other than that specified. Do not use combinations of old and new batteries or combinations of different types, different charging levels, different manufacturers or different models.

Precautions

- Please use a single power socket. Do not use any multiple socket inserted with multiple devices, this may cause a fire or electric shock.
- Do not use any power plug with wet hand in case of any electric shock.
- Do not use any AC power which is not within 100-240V.
- Do not disassemble or modify the printer without any authorization. This may lead to fire or electric shock.
- Please keep the printer away from alcohol, gasoline and other flammable solvents as well as any ignition source to prevent any deflagration and fire.
- Depending on the location, material, and environmental conditions, the label may unpeel or become irremovable, or the color of the label may change or be transferred to other objects. Before applying the label, check the environmental conditions and the material.
- Do not place the printer/batteries/AC adapter in direct sunlight or rain, near heaters or other hot appliances, in any location exposed to extremely high or low temperatures or high humidity, or in dusty locations.
- Do not try to print if the label cassette is empty; it may damage the print head.
- Do not pull the tape while printing or feeding; it will damage the tape and the printer.
- Any data saved in memory may be lost due to failure or repair of the printer, or if the battery expires.

Contents


<p>Label Printer</p> 	<p>Hard Case*</p> 	
<p>CD-ROM</p> 	<p>Lithium Battery**</p> 	
<p>Label Tape</p> 	<p>User Manual</p> 	<p>Power Adaptor</p> 
		<p>USB Cable</p> 

*and** are optional.

Specification

Printing Method	Thermal Transfer
Resolution	200dpi
Label Width	6mm / 9mm / 12mm / 18mm / 24mm
Printing Speed	Up to 20mm/s
File storage	Up to 64 files
Max. Height of Letter	18 mm
Fonts	8 fonts
Max. Labels No.	Up to 50 labels in 1 file
Keyboard	QWERTY layout
Display	LCD, Back-lit, 2-line info display
Printable Content	English letters, Numbers, Bar Codes, QR Codes, Symbols
Operating Environment	Temperature: 10°C ~ 35°C; RH: 20% ~ 80%RH
Power	AC 9V 3.5A
Measurement	160×129×65 (mm)


Power Supply




When using six new AA alkaline batteries or lithium batteries, make sure the poles are pointing in the correct directions.

To remove the batteries, reverse the installation procedure.


Insert a Tape Cassette



Open the back cover




Tighten the label, then insert the label cassette in position which marked in printer




Close the back cover

To insert a label cassette, follow the step above.
To remove the label cassette, reverse the installation procedure.








No.	Item	Introduction
1	Page	Current Label/All Labels; Editing Area/All Editing Area in One Label
2	Width	Label Width (6mm, 9mm, 12mm, 18mm, 24mm)
3	Length	Current label's length, "A" stands for automatic
4	Size	Current line's character size, "A" stands for automatic
5	Repeat	Repeat times of current label
6	Editing Interface	2-line display, each line up to 12 characters
7	Preview	【Shift】 + 【Template】 to turn on or off
8	Input Method	Current input method
9	Line Number	Line number in current label

Keyboard



Keyboard

No.	Key	Introduction
1	Esc	Stop printing process or ESC the current setting or operation to return to the previous level of menu or the input interface.
2		Turn on/off the printer
3	Print Options	Short press: print directly Long press: copy print; range print; cursor print; tempo print
4	En/Sy	Input modes: EA (English uppercase letter), Ea (English lowercase letter), Sy (Symbol)
5	Menu	Setting menu
6	Number 1-0	Short press: Number 1-0 Long press: Get into function menu
7		New/Save/Open/Delete file
8		Delete all
9	Add	Create new label
10		Backspace
11	Enter	Enter/Create new line
12		Move the cursor
13	Template	Insert label template
14	Wrap	Create wrap label
15	Flag	Create flag label
16	General	Create general label
17	Space	Space
18	Shift	Shift key

Functional Keys


Long press 1-0 to realize the functional keys

Number	Functional Keys	Second-level Directory
1	Length	Length; Margin; Char space; Lines space
2	Font	Font; Size; Width; Bold; Italic
3	Frame	Frame; Underline; 690Underline
4	Align	Center; Left; Right; Justify
5	Orientation	Horizontal; Vertical; Rotate; Mirror
6	Symbol	Unit; Number; Mathematics; Bracket; Punctuation; Arrow; Superscript; Subscript; Russian; Pinyin; Latin; Tabulate; Hiragana; Katakana; Safety; Electrical; Communicate; Prohibited; Transport; Office; Geometry; Animal; Insect; People; Food; Sports; Creativity; Daily Use
7	Barcode	Bar Code (CODE39, I-2/5, CODE128, EAN128, EAN13, EAN-8, UPC-A, UPC-E, CODABAR); QR Code
8	Sequence	0-999; 000-999; A-Z; a-z
9	Repeat	Range: 1-99
0	Cut	Cut; Solid line; None


Combination Keys

Combination Key	Introduction
【Shift】 + 【Print】	Copy Print; Range Print; Cursor Print; Tempo Print
【Shift】 + 【▲】	Move the cursor to previous label or same label's different area
【Shift】 + 【▼】	Move the cursor to next label or same label's different area
【Shift】 + 【◀】	Move the cursor to current label's beginning
【Shift】 + 【▶】	Move the cursor to current label's end
【Shift】 + 【←】	Delete all/current label/current line
【Shift】 + 【0-9】	Insert punctuations
【Shift】 + 【C】	Copy current line (not include sequence or barcode)
【Shift】 + 【V】	Paste the copy information
【Shift】 + 【W】	Adjust contrast ratio of LCD
【Shift】 + 【S】	Adjust brightness of LCD
【Shift】 + 【Flag】	DIY: create custom form
【Shift】 + 【Wrap】	Library: Preset label collections
【Shift】 + 【Template】	Preview the label outline
【Shift】 + 【M】	Turn on/off LCD back-lit


Create General Labels




Turn on the printer and input the content, such as SUPVAN.




Press Enter to create a new line and input the content, such as LP6245A.



To create a new label, press "Add" and it will automatically turn to page 2. Then input the content, such as LABEL2.




Label1



Label2


Create Flag Labels





To create a flag label, press “Flag”, then input the length, diameter and type details.

Length	Label’s length, can be automatic or specify (10-200mm)
Diameter	Tube’s diameter, can be automatic or specify (2-90mm) Perimeter= π *Diameter
Type	AA:AA; AA:BB

AA:AA




AA:BB




When making flag labels, please use Non Laminated or Strong Adhesive Label Tapes only.

Create Wrap Labels




To create a wrap label, press “Wrap”, then input the diameter details, choose inverse and repeat.


Diameter	Tube’s diameter, can be automatic or specify (3-90mm)
Inverse	Turn on/off inverse
Repeat	Repeat can only work for single line label.




Normal



Repeat




Repeat + Inverse




When making wrap labels, please use Wrap Label Tapes only.

Create Template Labels




To create a template label, press “Template”, then choose the template style you want.


Panel	4 different preinstall panel templates
Table	26 different preinstall table templates
Decorate Frame	86 different preinstall decorate frame templates




Panel



Table




Template



To choose a label from label library, press “Library”, then choose the label category you want.

Category	Office	Warning	Transport	Wishes	Sales
Quantities	33	8	6	14	19



Office



Warning



Wishes



Transport




Sales

This label printer can connect to computer.

System requirements:

Windows XP / Vista / 7 / 8 / 10

After installing the software, you can get more printing choices.



Troubleshooting

	Common problems	Fault cause	Handling methods
1	Turning on without LCD lighting up	<ol style="list-style-type: none"> 1. Wire between main control panel and keyboard control panel connected improperly or damaged 2. LCD disconnected or damaged 3. Keyboard control panel damaged 4. Main control panel damaged 5. Power supply not energized 	<ol style="list-style-type: none"> 1. Reconnect or replace the wire between main control panel and keyboard panel 2. Reconnect LCD or replace it 3. Replace keyboard control panel 4. Replace main control panel 5. Replace power supply
2	Turning on failure with lithium battery	<ol style="list-style-type: none"> 1. Lithium battery is damaged or low 2. Main control panel damaged 3. Wire between main control panel and keyboard control panel disconnected or damaged 	<ol style="list-style-type: none"> 1. Replace the lithium battery or recharge the battery 2. Replace main control panel 3. Reconnect or replace the wire between main control panel and keyboard control panel
3	Turning on failure with AA alkaline batteries	<ol style="list-style-type: none"> 1. The battery is low 2. The battery cable damaged or connected improperly 3. Main control panel damaged 4. Wire between main control panel and keyboard control panel disconnected or damaged 	<ol style="list-style-type: none"> 1. Replace the battery 2. Replace the battery cable or connect it properly 3. Replace main control panel 4. Reconnect or replace the wire between main control panel and keyboard control panel

Troubleshooting

	Common problems	Fault cause	Handling methods
4	LCD screen blurred	<ol style="list-style-type: none"> 1. LCD disconnected or damaged 2. Keyboard control panel damaged 	<ol style="list-style-type: none"> 1. Reconnect LCD or replace it 2. Replace keyboard control panel
5	Interface display "Install label" after consumable installation	<ol style="list-style-type: none"> 1. Consumable installed improperly 2. Non-matching consumables 3. Consumable's security chip damaged or no program 4. Consumable's security chip has excessive glue or dirt 5. Anti-counterfeiting unit of the printer damaged or metal contact deformation 6. Anti-counterfeiting unit of the printer connected improperly 7. Main control panel damaged 	<ol style="list-style-type: none"> 1. Install consumable properly by following the user manual 2. Use Supvan original consumables 3. Replace the consumable or update the program 4. Remove the excessive glue or dirt on consumable's security chip 5. Replace anti-counterfeiting unit of the printer 6. Connect the anti-counterfeiting unit properly 7. Replace main control panel

	Common problems	Fault cause	Handling methods
6	Label jam	<ol style="list-style-type: none"> 1. Consumable installed improperly 2. Labels layered pasted at the exit 3. Exit jammed 4. Full-cutter not reset 5. Print head compaction mechanism damaged 	<ol style="list-style-type: none"> 1. Install consumables properly by following the user manual 2. Replace good quality consumables 3. Clean out the printed labels at the exit 4. Replace the full-cut assembly or main control panel 5. Replace the print head compaction assembly
7	Abnormal sound when printing	<ol style="list-style-type: none"> 1. Foreign bodies in the printer 2. The internal gears damaged 3. Consumable installed improperly or damaged 4. Ribbon detect unit damaged 	<ol style="list-style-type: none"> 1. Clean out foreign bodies inside the machine 2. Replace the gears 3. Install consumables properly or replace with good consumables 4. Replace the ribbon detection unit

	Common problems	Fault cause	Handling methods
8	Unclear print	<ol style="list-style-type: none"> 1. Print head connection problem 2. Dirt on print head 3. Non-matching consumable 4. Print head is broken 5. Print head pressure weakened 	<ol style="list-style-type: none"> 1. Plug print head connection firmly 2. Use cotton alcohol swab to remove dirt from the print head 3. Use Supvan original consumables 4. Replace print head 5. Replace print head compaction assembly
9	Printer worked without content printed	<ol style="list-style-type: none"> 1. Printing content is space 2. Back cover not installed 3. Print head connected improperly 4. Print head is broken 5. Main control panel damaged 6. Main motor photoelectric detect unit damaged or fall off 7. Keyboard control panel damaged 8. Battery is low 	<ol style="list-style-type: none"> 1. Input the content 2. Close the back cover 3. Plug print head connection firmly 4. Replace the print head 5. Replace main control panel 6. Replace main motor photoelectric detect unit or reinstall it 7. Replace keyboard control panel 8. Replace battery

Troubleshooting

	Common problems	Fault cause	Handling methods
10	Print content incomplete	<ol style="list-style-type: none"> 1. Print head connection problem 2. Dirt on print head 3. Non-matching consumable 4. Print head is broken 5. Ribbon knitted 	<ol style="list-style-type: none"> 1. Plug print head connection firmly 2. Remove dirt from print head 3. Use Supvan original consumables 4. Replace print head 5. Replace consumable
11	Uncuttable	<ol style="list-style-type: none"> 1. Battery is low 2. Cutter's life is overdue 3. Glue on the cutter 4. Full-cut transmission assembly damaged 	<ol style="list-style-type: none"> 1. Replace the battery 2. Replace the cutter 3. Clean the cutter with a cotton swab 4. Replace the full-cut transmission assembly
12	Interface display "Printing..." without printer working	<ol style="list-style-type: none"> 1. Full-cut transmission assembly damaged 2. Full-cut detection unit connected improperly or damaged 3. Main motor connected improperly or damaged 4. Main control panel damaged 5. Keyboard control panel damaged 6. Program lost 	<ol style="list-style-type: none"> 1. Replace the full-cut transmission assembly 2. Reconnect the full-cut detect unit or replace it 3. Reconnect the main motor or replace it 4. Replace main control panel 5. Replace keyboard control panel 6. Replace keyboard control panel

Troubleshooting

	Common problems	Fault cause	Handling methods
13	No detection after consumable depletion	<ol style="list-style-type: none">1. Ribbon photoelectric detect unit connected improperly or damaged2. Main control panel damaged	<ol style="list-style-type: none">1. Connect the ribbon photoelectric detect unit properly or replace it2. Replace main control panel
14	Interface display “Label run out, Replace new”	<ol style="list-style-type: none">1. Consumable used up2. Consumable anti-fake chip damaged	<ol style="list-style-type: none">1. Check if the consumable is used up. Change it if necessary.2. Replace new consumable
15	Label involved in rubber roller	<ol style="list-style-type: none">1. Consumable used up without detection2. Glue on rubber roller	<ol style="list-style-type: none">1. Test if the photoelectric detect unit damaged or connected improperly2. Clean glue on rubber roller
16	Ribbon rewind shaft not work	<ol style="list-style-type: none">1. Glue on the consumable2. Unwinding force of ribbon is too strong	<ol style="list-style-type: none">1. Clean the glue on consumable or skip this length2. Replace the consumable
17	Automatically stop without printing content	<ol style="list-style-type: none">1. Consumable used up without detection2. Ribbon photoelectric detect unit lost efficacy	<ol style="list-style-type: none">1. Replace the consumable2. Replace ribbon photoelectric detect unit

Symbol

Unit													
°	'	"	\$	¥	₹	¢	£	%	@	°C	°F	\$	%
‰	@	mil	cm	km	KM	m ²	mg	kg	cc	°	○	⊗	€
⊕	m ³	ml	mol										

Number														
i	ii	iii	iv	v	vi	vii	viii	ix	x	I	II	III	IV	V
VI	VII	VIII	IX	X	XI	XII	1.	2.	3.	4.	5.	6.	7.	8.
9.	10.	11.	12.	13.	14.	15.	16.	17.	18.	19.	20.	(1)	(2)	(3)
(4)	(5)	(6)	(7)	(8)	(9)	(10)	(11)	(12)	(13)	(14)	(15)	(16)	(17)	(18)
(19)	(20)	①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩	(-)	(=)	(≡)
(四)	(五)	(六)	(七)	(八)	(九)	(十)	⑪	⑫	⑬	⑭	⑮	⑯	⑰	⑱
⑲	⑳	●	●	●	●	●	●	●	●	●	●	●		

Symbol

Mathematics

≈	≡	≠	=	≤	≥	<	>	≠	≠	::	±	+	-	×
÷	/	∫	∫	∞	∞	∧	∨	Σ	Π	∪	∩	∈	∴	∴
⊥	//	∠	∩	⊙	≅	∞	√	≅	≅	≅	≅	+	-	<
>	=	~	⊥	△	log	ln	¼	½	¾					

Bracket

()	⌒	⌒	{	}	⌒	⌒	()	⌒	⌒	【	】	⌒	⌒	《	》
≅	≅	<	>	⌒	⌒	「	」	┌	┐	『	』	⌒	⌒	()	{	}
()	‘	’	“	”	”	”	、	、								

Punctuation

,	、	。	。	；	：	？	！	：	…	’	、	々	~	
˘	-	,	、	。	•	；	：	？	！		-		—	
{	—	#	&	*	※	§	”	№	⊕	%	-	—	—	---
--	---	--	—	—	#	&	*	♀	♂	⊕	⊙	//		/
\	/	\	am.	pm.	⊕	⊕	⊕	⊕	⊕					

Symbol

Arrow

↑	↓	←	→	↖		↗	↘	↙	↘	↙	↘	↙	↘	↙
↕	↔	↗	↖	↘	↙	↻	↻	↻	↻	↔	↔	↕	↕	↔
↕	↔	↗	↖	↘	↙	↻	↻	↻	↻	↔	↔	↕	↕	↔
↔	↔	↔	↔	↔	↔	↔	↔	↔	↔	↔	↔	↔	↔	

Superscript

..	©	ª	®	º	²	³	¹	º	•	/	//	\	TEL	™
“	”	°	±	+	-	⁴	⁵	⁶	⁷	⁸	⁹	ᵃ	ᵇ	ᶜ
ᵉ	ᵈ	ᶠ	ᵍ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ	ᵇ	ᶜ
ˢ	ᵀ	ᵁ	ᵂ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ				

Subscript

ˆ	±	+	-	₀	₁	₂	₃	₄	₅	₆	₇	₈	₉	ₐ
ᵇ	ᶜ	ᵉ	ᵈ	ᶠ	ᵍ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ	ᵇ	ᶜ
ᵍ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ	ᵇ	ᵃ	ᵇ

Symbol

Russian

А	Б	В	Г	Д	Е	Ё	Ж	З	И	Й	К	Л	М	Н
О	П	Р	С	Т	У	Ф	Х	Ц	Ч	Ш	Щ	Ъ	Ы	Ь
Э	Ю	Я	а	б	в	г	д	е	ж	ё	з	и	й	к
л	м	н	о	п	р	с	т	у	ф	х	ц	ч	ш	щ
ъ	ы	ь	э	ю	я									

Pinyin

ā	á	ǎ	à	ō	ó	ǒ	ò	ē	é	ě	è	ī	í	ǐ
ì	ū	ú	ǔ	ù	ǖ	ǘ	ǚ	ù	ü	ê	α	ín	ń	Ǻ
ñ	g													

Latin

A	B	Г	Δ	E	Z	H	Θ	I	K	Λ	M	N	Ξ	O
Π	P	Σ	T	Υ	Φ	Χ	Ψ	Ω	α	β	γ	δ	ε	ζ
η	θ	ι	κ	λ	μ	ν	ξ	ο	π	ρ	σ	τ	υ	φ
χ	ψ	ω												

Symbol

Tabulate

┌	┐	└	┘	┙	┚	┛	├	┤	┥	┦	┧	┨	┩	┪	┫
┬	┴	┵	┲	┳	┴	┴	┴	┴	┴	┴	┴	┴	┴	┴	┴
┌	×	┐	└	┘	┙	┚	┛	├	┤	┥	┦	┧	┨	┩	┪
┌	┐	└	┘	┙	┚	┛	├	┤	┥	┦	┧	┨	┩	┪	┫
┌	┐	└	┘	┙	┚	┛	├	┤	┥	┦	┧	┨	┩	┪	┫
┌	┐	└	┘	┙	┚	┛	├	┤	┥	┦	┧	┨	┩	┪	┫
┌	┐	└	┘	┙	┚	┛	├	┤	┥	┦	┧	┨	┩	┪	┫
┌	┐	└	┘	┙	┚	┛	├	┤	┥	┦	┧	┨	┩	┪	┫
┌	┐	└	┘	┙	┚	┛	├	┤	┥	┦	┧	┨	┩	┪	┫
┌	┐	└	┘	┙	┚	┛	├	┤	┥	┦	┧	┨	┩	┪	┫

Hiragana

あ	い	う	え	お	か	き	く	け	こ	さ	し	す	せ	そ	た	ち
つ	て	と	な	に	ぬ	ね	の	は	ひ	ふ	へ	ほ	ま	み	む	め
も	や	ゆ	よ	ら	り	る	れ	ろ	わ	を	ん	が	き	ぎ	ぐ	げ
ざ	じ	ず	ず	ぞ	だ	ぢ	づ	で	ど	ば	び	ぶ	べ	ぼ	ぱ	ぴ
ぷ	ぺ	ぽ	ぱ	ぴ	ぷ	ぺ	ぽ	あ	い	う	え	お	や	ゆ	よ	っ
わ	ゐ	ゑ														

Symbol


Katakana

ア	イ	ウ	エ	オ	カ	キ	ク	ケ	コ	サ	シ	ス	セ	ソ	タ	チ	ツ
テ	ト	ナ	ニ	ヌ	ネ	ノ	ハ	ヒ	フ	ヘ	ホ	マ	ミ	ム	メ	モ	ヤ
ユ	ヨ	ラ	リ	ル	レ	ロ	ワ	ヲ	ン	ガ	ギ	グ	ゲ	ゴ	ザ	ジ	ズ
ゼ	ゾ	ダ	ヂ	ヅ	デ	ド	バ	ビ	ブ	ベ	ボ	ァ	ィ	ゥ	ェ	ォ	ャ
ュ	ョ	ッ	ヴ	ヰ	ヱ	カ	ケ										

Safety

Symbol

Electrical



Communicate




Symbol


Prohibited



Transport




Office



Symbol


Geometry



Animal



Insect




Symbol

People



Food




Sports




Symbol

Creativity




Daily Use




Template Details


Panel



Table



Decorate Frame



Library Details

Office







pending	ASAP!	please sign and return	FINISHED	personal
Standby	CONFIDENTIAL	DO NOT CIRCULATE	URGENT	FOR YOUR INFORMATION
PLEASE BE QUIET		FOR INTERNAL USE ONLY		OUTGOING MAIL
OUTGOING MAIL	KEEP CLOSED	NO MOBILE PHONE	NO PHOTOGRAPHY	
NO VIDEO	AUTHORIZED PERSONAL ONLY	ROAD CLOSED	DRINKING WATER	
NO SMOKING		NO SMOKING		KEEP CLEAN
DO NOT DISTURB	NO FOOD		TURN LIGHT OFF	
REFERENCE ROOM	VISITOR REGISTRATION		NO ADMITTANCE	
TRASH CAN	RECYCLE BIN		BATTERY	

Warning

DO NOT TOUCH	CAUTION! NOT!	WATCH YOUR STEP	DANGER!
CAUTION!	WARNING!	NO ENTRY	ELECTRICAL HAZARD!

Library Details

Transport

 THIS SIDE UP	=NO CURVE=	 FRAGILE 
 HANDLE WITH CARE	 CARRY WITH CARE	 KEEP DRY

Wishes

 HAPPY BIRTHDAY	 MERRY CHRISTMAS	 HAPPY NEW YEAR
 HAPPY FATHER'S DAY	 HAPPY MOTHER'S DAY	 THANKS TEACHER
 HAPPY ANNIVERSARY	 HAPPY EVERY DAY	 THANKS
 I LOVE YOU	 BEST WISHES	 GOOD LUCK
 SURPRISE	 HAPPY VALENTINE'S DAY	

Sales

 SALE	 BEST SELLER	 WEEKLY BEST SELLER	 SPECIAL DEAL	 MANAGER RECOMMENDED
 CLEARANCE	 NEW ARRIVAL	 PUSH	 PULL	 OPEN
 CLOSE	 SALE SALE	 SPECIAL DISCOUNT	 PRESALE	 SAMPLE
 2nd BUY 1 GET 2nd ONE 50% OFF	 TODAY'S SPECIAL	 HANDLE MADE	 GIFT	

SUPVAN

Organized, Simple, Done.